

www.LGUSA.com

# CG225 Quick Start Guide

VGA Camera with up to 4x Zoom



Multimedia Messaging (MMS)



Speakerphone







#### **Getting to Know Your Phone**



#### **Taking Pictures**

Capture everything around you in vivid detail through the VGA camera with up to 4x zoom\*. Then share it instantly with friends via multimedia messaging.

- 1. From standby mode, press the **Camera Key**.
- Press left or right on the Navigation Key to adjust brightness and up or down for zoom\*. Press the Right Soft Key to adjust image size, self timer, multishot and other options.
- 3. Press  $\times$  to take the picture.
- 4. To send your picture, press the **Left Soft Key** for **Send**. Add text to personalize your message, then press  $\chi$  to enter recipients. To choose a contact from your address book, press  $\chi$ .
- 5. Press the **Left Soft Key** to send.





# **Instant Messaging**

If you subscribe to an instant messaging (IM) service such as AOL, MSN, Yahoo! or ICQ, you can take the fun and convenience of IM on the go with your mobile phone.

- 1. From standby mode, press **right** on the Navigation Key to access IM.
- 2. Highlight the IM community you want to enter and press X.
- 3. The first time you enter a community, enter your **Screen Name/ID** or **E-mail** and your **Password** and press X.
- 4. Select a contact that is currently online and press X.
- 5. Enter your message and press  $\times$  to send. To end a chat, select **Option**, then **End Conversation (3)**.



**Note:** When you receive an incoming instant message, a "new message" icon similar to this one will appear on the screen.

Screens vary by IM community.

# Multimedia Messaging

Snap it. Say it. Share it. Multimedia messaging lets you share photos, voice messages and more!

- 1. From standby mode, press the **Left Soft Key** for **Menu**, then select **Messaging (2)**.
- 2. Select New Message (1), then Multimedia (2).
- 3. Write your message, then press the **Right Soft Key** for **Options**. Select **Insert (1)** and press X.
- 4. Choose **Graphic (2)** to access your photo album or **Audio (3)** to add a short audio. Select the desired photo or sound and press .
- 5. Press X to enter recipients. To choose a contact from your address book, press X.
- 6. Select a contact and press X. Then press X again to send.



#### Downloadable Fun

Get access to the latest downloadable games and graphics, plus new ringtones from today's hottest artists. Personalize your phone today!

- From standby mode, press the Right Soft Key for Mall.
- 2. Select **Shop Tones (1), Shop Games (2)** or **Shop Graphics (3)** and press X.
- 3. When your web connection is established, choose a category, and press X.



Note: Downloaded files will be stored in My Stuff (7) under Audio (3) or Graphics (4).

### Speakerphone

Your phone includes built-in speakerphone functionality to allow for a truly hands-free conversation!

- 1. During a call, press the **Right Soft Key** for **Options**.
- 2. Select Speaker On (1).
- 3. To deactivate, press the **Right Soft Key** for **Options**, then select **Speaker Off (1)**.



# **Optional Accessories**

Accessories for productivity, convenience and fashion are available at www.LGUSA.com.



Mobile Charger









Headset

Carrying Case

Serial Data Cable

© 2006 LG Electronics, Inc. All rights reserved. All other trademarks are property of their respective owners. All phone images are simulated.